

# **Network Video Monitor Software**

## **V2.0.0.7**

**Operation menu**

# **Chapter 1 Product Overview**

## **1.1 Performance instruction**

Network video monitoring software is a centralized management software for I8 protocol surveillance devices which include NVR, DVR, IPC, MDI, SDI, etc. It support video preview, playback, electronic map, TV wall, Log, configuration and other kinds of functions, greatly promoted the users supervision and control.

Each PC only support one software operation, it is free for I8 protocol products access, it is free for 16 PCS ONVIF protocol products access. Other protocol products access need authorization ( Without authorization, it only support 1 product access).

**Note:** After authorization, the automatically memory function let the accessed devices number recorded, users have to delete the recorded channels information as the front devices log out.

## **1.2 System operation environment**

Operation system: Microsoft Windows XP or later


CPU: Intel(R) Celeron(R) CPU E3400 @2.6GHZ or later


HDD: 2G or later

Network: Gigabit network interface controlle for PC, Gigabit network for interchanger

# Chapter 2 Software Introduction

Installation instruction


Double click installation program icon  to operate the software, and the below interface will pop out, select the language version, and click “OK”:




Click **Next** to go to store location selection interface, users can click

[Browse...](#)


to select the store location file:




Click **Next**, and the below interface will pop out, it will convenient to select **Create a desktop icon**:



Click **Next**, it will create a desktop icon and then click **Install**, meanwhile software installation running.







Click Finish to complete installation.

After software installation successfully, click the corresponding

desktop icon  to operate it. The follow interface will pop out, input username and password ( Default Username is root, password is blank) to log in. Any modification for ADMN please go to client-side to handle:



As log in the main interface, it divide into 6 modules include **Preview**, **Playback**, **Map**, **TVwall**, **Log**, **Config**:



**CPU:43% MEMORY:72%** is the computer CUP and In-memory data,

means alarm information coming, and the details alarm information as below:

Real-time Alarm events					
time	type	source	remark	state	
1 2014-10-17 17:50:39	AlarmInput	CMS-NVR_12.120.130.248-NetAlarmIn1		Alarm Begin	
2 2014-10-17 17:50:40	AlarmInput	CMS-NVR_12.120.130.248-NetAlarmIn2		Alarm Begin	


**User: root** is the current client logged in user.

**Note:** When you have to log out, please click icon at the display right corner, it is useless to click icon at top right corner.

## 2.1 Video preview and recording

Double click the selected device address information at the left list,

and the device corresponding channels will come out, double click the selected channel or drag the selected channel to right window to open the video preview( There is a triangle icon at the channel number left when the corresponding channel device operation ). See as below:



### 2.1.1 Right mouse button for devices /channels

- Channels status
  - 1) There is a same circle icon behind the channel number and the preview window right corner, blue icon means video recording not open, red icon means video recording open.
  - 2) When you selected the video preview window, the corresponding channel number on left list will turn blue. As



- Right mouse button for devices

- 1) Open all preview

Click right mouse button at device to select open all video preview

- 2) Close all preview

Click right mouse button at device to select stop all video preview

- 3) Open all record

Click right mouse button at device to select and then start all channel devices video recording

- 4) Close all record

Click right mouse button at device to select close all channel devices video recording

- 5) All channel main stream

Select the devices, set all channel video images mode to main stream

- 6) All channel sub-stream

Select the devices, set all channel video images mode to sub stream

- 7) Start/stop intercom

## **2.1.2 Right mouse button for windows**

### 1) Stop preview

Click right mouse button to stop the selected window video preview

### 2) Capture

Click right mouse button to do real-time capture for preview interface, and then store the capture file to specified directory

### 3) Start/ Stop record

Click right mouse button to start or stop the the corresponding channel local video recording

### 4) Open/ Close sound


Click right mouse button to set open or close the corresponding channel audio preview( There are only support opening one channel sound simultaneously)

### 5) Stop all preview/ tour

Click right mouse button to stop all video preview or group tour preview

### 6) Full screen/ Exit full screen

### 7) Image process




There are defog, image enhance, dejitter functions.

## 8) Main stream/ sub stream

Click right mouse button to select the stream type according to screen display need

## 9) Playback



There is the video playback interface, More details for operation steps please refer to **video playback** module introduction.

### 2.1.3 Single preview windows toolbar


 show the device name at the toolbar left, gray icon  means front device does not do video recording (Green icon  means front device is doing video recording), blue icon  means local channel does not do video recording (red icon  means local channel is doing video recording),  means capture,  means open or close the sound.

### 2.1.4 Total video preview windows toolbar

 respectively is Set split-screen, Start/ Stop polling, Last group, Next group, Stop all preview/ Polling.

### 2.1.5 Device video group polling

Add two or more then two channels video to compose a group( More details for operation steps please refer to **Config** module introduction), Click  icon to start group video polling. As figure below:




Click the  icon once again to stop group video polling,

Click  icon to close group video polling.

## 2.1.6 PTZ

### 2.1.6.1 PTZ control

Click **PTZ** , it control the camera lens 8 directions respectively is Up, Down, Left, Right, Up left, Down left, Up right, Down right, Zoom +/-, Focus+/-, Apert +/-, PTZ speed, Light, Wipers, Fan. As figure below:



### 2.1.6.2 Preset

Click **Preset** to enter into preset setting interface:

No.	Preset Name
1	
2	
3	
4	
5	
6	
7	
8	

Buttons at the bottom: Set, Clear, Call.

Turn the camera lens to appointed location, and select the serial number, click **Set** and there is a “Set Preset Name” interface pop out, edit preset name and click **OK**.



If you want to modify the preset location, turn the camera lens to appointed location directly and click **Set** to change and save it. Total configurable presets depend on front device supporting.

Click **Clear** to delete the setted preset


Select the serial number and click **Move to**, the camera will go to the corresponding setted location directly.

#### 2.1.6.3 Cruise

Click **Cruise** to enter into preset setting interface:

PTZ	Preset	Cruise	Param
No.	Cruise path name		
1			
2			
3			
4			
5			
6			
7			
8			

Select a serial number and click **Set**, the below interface will pop out:




Input the cruise name, click **Add**, and select the specified preset, then set the cruising time and speed. Repeat above operation to add the second and third cruising point, configurable cruise point numbers depend on front device supporting.

Select the cruising point number and click **Delete** to delete the corresponding cruising point,

After complete the setting, click **Save**. Click **Call** to start cruising, and click **Stop** to close the cruising.

#### 2.1.6.4 Param

Click **Param** to enter into parameters setting interface:




Set the selected channel preview window brightness, contrast, saturation and tone, click **default value** to make the parameters restore default. It only support brightness and contrast setting for current I8 protocol.

### 2.1.7 Preview window video image electronic zoom

As select the channel preview window, it support video image electrical smooth zoom in by mouse middle button wheel operation.

## 2.2 Video playback

Click **Playback** to go to video playback module, as figure below:



### 2.2.1 Local video search

Click  icon in front of the device information while all channels following this device will be selected, click  icon in front of  icon to show the scope selection drop-down list, and determine to search the needed channels video( Each device only support 9channels video playback at the same time, different devices record video can not playback at the same time). Set the date, select record scope(**Local video/ Device video**) and click **video search** to view the record video. As figure below:



## 2.2.2 video playback operation

Click to play, click to stop, double-click on the blue video progress bar can pinpoint playback. As figure below:




In the playback interface, double-click a playing window can get a

preview interface full-screen display, or right mouse click on the playing window to select **Full screen**, it will get a displayer full-screen display.

### 2.2.3 Record download


Click  icon to download the video image, there a video record download page will pop out. As figure below:



Select the video location(Remote/ Local), download channel, time interval and video store path, click start or stop to download, the file will save in the specified path.

Attention: It is best to use VLC media player to play the downloaded file.

## 2.2.4 Tool bars


 capture,  control the speed of playback,  open or close the voice(It only support 1 channel voice playing every time),  1, 4, 9 split screen switch.

## 2.2.5 Playback image electronic amplification


During video playback, select one window and scroll with the mouse, the video image will Zoom in.

## 2.3 Electronic map / Configuration map

Click **Map** to enter into map function module,  means the electronic map are opening( \*Electronic map). As figure below:




Click  and it will change to  , it means the electronic map are in configuration( \*Configuration map). As figure below:




### 2.3.1 Add map

Configuration map  status, right mouse click on  **Maps** and select **New Map**, the follow interface will pop out,



Edit the map name and add a map picture, click OK, the map added successfully:



When the electronic map display, the corresponding name will turn to

blue map 1  
blue map 2

### 2.3.1.1 Right-click on map name

- Delete map

Delete the current map

- Add child map


Add a sub map for the current main map, icon will appear on the main map, there are only 2 levels for each main map, so it can not add a new map under the sub map. double click to open the sub

map( It is only available for the Electronic map status)

Click icon on sub-map to return to the main map.

### 2.3.1.2 Right-click on / icon


Select the channel in the device list and drag on the map to successful set up a defence, there are tow kinds of icon / . As figure below:



Right mouse click on the icon to select delete the defence or change the icon / .

### 2.3.2 Electronic map

Click to the electronic map :



2.3.2.1 Right mouse click on / icon


- Channel preview
- Channel playback (More details for operation steps please refer to **video playback** module introduction).

### 2.3.3 Map widening , narrowing and full screen


2.3.3.1 Electronic map support the mouse scroll to widening and narrowing

2.3.3.2 icon used to widen screen map, icon used to close the full screen map

## 2.4 TV -Wall



Decoder list is used to add new decoder and show the added decoders. Right mouse click on Decoder , select **Add decoder** , the follow interface will pop out, As figure below:



Input the device IP, port, device name of decoder and then click OK. If there are many decoders, click search and open the search interface. As figure below:


	Device SN	Device Type	IP	Subnet Mask	Port	Device Name	User Name	Password	
1	<input type="checkbox"/> 01401010611...	DEC-140-16CH	192.168.1.179	255.255.255.0	5050	Dec_192.168.1.179	admin		<b>Modify IP</b>

Select All      **Search**      **Select**      **Batch Add**      **Cancel**

Check multiple decoder devices , click **Bulk add**. Or check and add the decoder device one by one.

#### 2.4.1 Add ordinary decoder matrix

After add the decoder, according to the TV-wall to set matrix display through the toolbar on the screen below  (Or click right mouse button-add preview window), input the numbers and click **SET**. As figure below:




Preview window right-click menu: Add new preview window /delete

Preview window .

#### 2.4.2 Add joint decoder matrix

Preview window right-click to add new preview window and according to the TV wall to set it directly, as figure below:




Preview window right-click menu: Add new preview window /delete

Preview window .


### 2.4.1 TV-wall daily

TV-wall daily include decoder preview and decoder rotation. Drag the decoder to the matrix, there will appear relevant information about decoder on the screen. As figure below:



#### 2.4.1.1 Video image resolution

Click the right mouse button on preview window to select the video image resolution, as figure below:



Mode: (720\*576) \*16 means the highest resolution is 720\*576,

and support max 16 channels preview at same time

Mode: (1280\*960) 9 means the highest resolution is 1280\*960,  
and support max 9 channels preview at same time

Mode: (1920\*1080) 4 means the highest resolution is 1920\*1080,  
and support max 4 channels preview at same time

**Note:**

- Different decoder have different resolution mode, high resolution is compatible with low resolution video image, but low resolution can not analysis the high resolution video image.
- Users can select the video resolution only for No.3521 and No.3520D decoder board. As the No. 3535 decoder board does not support resolution right mouse click to select, users can split screen to change the video image resolution, 4screen: 1920\*1080, 9 screen: 1280\*720.
  -  icon shows the condition of decoder:
    -  means the decoder is used to preview only
    -  means the decoder is used to rotation only
    -  shows the decoder status of set/remove defence
    -  means the decoder removed the defence and can not support video display on the TV wall
  -  means the decoder set the defence and can support video


display on the TV wall

 means it is used to delete the channel of decoder : select the split screen, and click   
 icon is used to amend the split screen of decoder

Right click: Delete matrix output/ widening display


#### 2.4.1.1 Decoder preview

Transfer the wall into preview status , drag the device channel into decoder split screen directly. As figure below:



#### 2.4.1.2 Decoder rotation

Transfer the wall into rotation status , it indicate the wall is in rotation condition. User add channels into group. As figure below:




- Right mouse click to select the video channel

Delete group: Select the group and right mouse click to select deletion

Modify name: Select the group and right mouse click to select name modification

Delete node: Delete the group channels

After added group successfully, double-click a group icon into configuration state . Then drag the channel to the group , the dragged channels will be recorded in the decoder. As figure below:



- Rotation operation buttons



While all group are setting done, click  to open rotation.



switch to last group to monitoring



switch to next group to monitoring




close the rotation

Polling Interval	30	<input type="button" value="SET"/>
------------------	----	------------------------------------


it is used to set the time of rotation.

## 2.4.2 TV-wall playback

Click playback to check the record video. As figure below:



One decoder only support one channel record video playback at every time, each device only support 9channels video playback at the same time, different devices record video can not playback at the same time. Drag channels to the decoder then select the time and position of video, finally click the button of video search. As figure below:



click to play record video, or precisely click the record video blue bar directly


close the playback

control the playback speed.

Ordinary decoder matrix right mouse click: Screen magnification(Client)

Joint decoder matrix right mouse click: Video image 1 divide 4, normal images stitching.

## 2.5 Log



### 2.5.1 Alarm logs

Alarm logs: It can be search out as the front device marked alarm signal upload center, it can be search out if check the alarm of upload center in device side which respond to the alarm linkage rule in client-side. It will show the relevant information of rules in linkage action and playback. As the figure below:

Video Monitor Client									
Preview		Playback		Map		TV wall		Log	Config
Alarm Logs		Operation Logs		Remote Logs				CPU:73% MEMORY:30%	User: root
Search condition		2015-3-16 0:00:00		to		2015-4-15 0:00:00		Type	All Type
								Search	
Alarm Type		Alarm Source		Remark		Begin Time		End Time	
1	Motion	CMS-IPC_192.168.1.188-CH01				2015-03-16 13:48:40		2015-03-16 13:49:03	
2	Motion	CMS-IPC_192.168.1.188-CH01				2015-03-16 11:12:43		2015-03-16 11:13:18	
3	Motion	CMS-IPC_192.168.1.188-CH01				2015-03-16 11:12:18		2015-03-16 11:12:42	
4	Motion	CMS-IPC_192.168.1.188-CH01				2015-03-16 11:11:00		2015-03-16 11:11:40	
5	Motion	CMS-IPC_192.168.1.188-CH01				2015-03-16 11:10:14		2015-03-16 11:10:38	
6	Motion	CMS-IPC_192.168.1.188-CH01				2015-03-16 11:08:23		2015-03-16 11:08:47	
7	Motion	CMS-IPC_192.168.1.188-CH01				2015-03-16 11:08:05		2015-03-16 11:08:20	
8	Motion	CMS-IPC_192.168.1.188-CH01				2015-03-16 09:47:28		2015-03-16 09:48:05	
9	Motion	CMS-IPC_192.168.1.188-CH01				2015-03-16 09:46:46		2015-03-16 09:47:09	
10	Motion	CMS-IPC_192.168.1.188-CH01				2015-03-16 09:46:01		2015-03-16 09:46:46	
11	Motion	CMS-IPC_192.168.1.188-CH01				2015-03-16 09:45:19		2015-03-16 09:45:43	
12	Motion	CMS-IPC_192.168.1.188-CH01				2015-03-16 09:44:25		2015-03-16 09:44:48	
13	Motion	CMS-IPC_192.168.1.188-CH01				2015-03-16 09:43:28		2015-03-16 09:44:10	
14	Motion	CMS-IPC_192.168.1.188-CH01				2015-03-16 09:41:43		2015-03-16 09:42:52	
15	Motion	CMS-IPC_192.168.1.188-CH01				2015-03-16 09:41:11		2015-03-16 09:41:34	
16	Motion	CMS-IPC_192.168.1.188-CH01				2015-03-16 09:39:58		2015-03-16 09:41:05	

The type of alarm can be divided into alarm input, motion detection, video shelter, video lost.

Alarm source come from the device channels.

Begin time and end time is the time of alarm triggered and the time of alarm stop.

Linkage action shows the relevant linkage rule information, such as there will show **pop image** chars if set video action linkage.

In the playback,  icon indicate that there a record video, click the  icon to play.

 mean the alarm capture, double click to check.


## 2.5.2 Operation logs

Operation logs : All users operations will be recorded, and the

operation type include: All type, log in/out, add/ delete devices, setup/ cancel alarm, open/ close record, remote configuration, set alarm linkage.

### 2.5.3 Remote logs


Remote log is to search the alarm information saved in the front-end device. Select the front-end device, set date and type then click **Search**, all alarm information of the preset time period will appear in the blank area. As figure below:



## 2.6 configuration

### 2.6.1 Device manage

Click and enter into the configuration page. As figure below:




### 2.6.1.1 Right mouse click on CMS icon

- Add area

Right mouse click to add a new sub-area, input the area name and save it.

- Add device

Right mouse click to select **Add device**, and the follow interface will pop up:



It support 4 kinds protocol products: I8, ONVIF, Hiklife, Dahua.

Click **Search** can add I8, ONVIF, Dahua protocol products.

Input the device information manually and click OK to add successfully, or click **Search** to search online devices, the follow interface will pop up:

Search online device-I8

	Device SN	Device Type	IP	Subnet Mask	Port	Device Name	User Name	Password	
1	02621010696...	IPC-262-1CH	192.168.1.188	255.255.255.0	5050	IPC_192.168.1.188	admin		<input type="button" value="Modify IP"/>
2	02641010699...	IPC-264-1CH	192.168.1.189	255.255.255.0	5050	IPC_192.168.1.189	admin		<input type="button" value="Modify IP"/>
3	02641010692...	IPC-264-1CH	192.168.2.158	255.255.255.0	5050	IPC_192.168.2.158	admin		<input type="button" value="Modify IP"/>

Select All                       

Modify IP address: Click  to modify the device IP parameters (It can not get the subnet mask and gateway for Onvif protocol devices). As figure below:

Modify Device Network Parameters -I8


Device SN	02641010699a1aa30939
Device IP	192.168.1.189
Subnet Mask	255.255.255.0
Gateway	192.168.1.1
DNS1	202.210.230.255
DNS2	202.210.255.255

Search: Click  again to update the device information

Select: Select one device and click to select, add the device into CMS.

As figure below:



Batch add: check one or more device simultaneously, click the **Batch add** to add series devices one-time .

Cancel : Close the device online search window

Note: Users may have to input the ONVIF product password when click **Search** button to select device.

- Modify the device

Modify the added devices IP, port, user name and password.

- Modify the name

Modify the area/device name


- Refresh channel name

Right mouse click to select to refresh the channel name

- Set alarm

Click to open alarm linkage


- Set IP channel



Click **Search** to list the IPC in “online IPC” then select IPC and click **->**, add it to “NVR channel” successfully.

Select the channel in “NVR channel”, click **<-** to cancel channel click **Up** to move up channel, click **Down** to move down channel.

Double-click the device in “online IPC” list, users can change IP param in “modify IPC net param” interface.



Double-click the “NVR channel”, input the correct param (user name and password) in “NVR channel param” interface to ensure NVR connect IPC successfully.

NVR Channel Param

channel	Channel2
protocol	I8
IP	192.168.38.186
port	5050
stream	MainStream
network	TCP
play mode	Smooth
user	admin
Password	admin
<b>modify</b>	

- Delete node

Right mouse click on the device information to select delete node(As any present device channels video in the preview/playback/ recoding, it can not delete)


- Modify device

Right mouse click to to select **modify device**, and users and eidt the device local name

### **2.6.1.2 Access controller**

- Add access controller

Right mouse click on  icon to select **Add access controller**, and the below interface will pop out:



Users can input the access controller device IP and other information, or click **Search**, as figure below:

	SN	IP	Gateway	Subnet Mask	Port	Mac Address	Access Controller Name
1	0153941	192.168.0.72	192.168.0.1	255.255.255.0	60000	00:06:121:16...	MJdev_192.16...

Batch add: Select devices and click batch add.

Cancel: Close the online devices window.

- Access controller status

After the access controller add successfully, as figure below:




Door1: Attendance & access system controlled the door1, means door open, mean door closed;

Reader 1/2: Card reader 1, Card reader 2;


Button 1: Button 1 for the door open/close.

- Attendance & access system setting

Right mouse click on the access device name, as figure below:



Modify network parameters: Modify the IP address, as figure below:




Delete node: Delete the attendance & access system

Sync device time: Set the attendance & access system time same with PC client

Modify node name: Select to modify the access device name


- Door remote operation

Right mouse click on the **door 1** and select **Remote Open door**, and open the door. As figure below:




### 2.6.1.3 Remote configuration

Select the device and click **remote config**:





Remote configuration can be used to modified device parameter, more specific operations please refer to device specification manual.

#### 2.6.1.4 Right click to add group node

- Right click on  Channel Group icon to add group
- Right click on group name to select **Delete group** to delete it
- Select the device channel in the left area, and select specified group in the right area, click  then click  to add the channel in the specified group.
- Select the device information in the right area and click  to remove it
- Select the group and click ,  to sorting it.

#### 2.6.2 local config

Click  enter into the local configuration page. As figure below:



- Capture file path/ Download file path: Set the file store path. Click **Open** to find the file location.
- Group polling time: Set the group preview time 10 seconds in general.
- Alarm sound configuration:




Users can set the custom alarm sound , click to select the audio file, change the old audio file into the new audio file, click to

preview audio file .

Attention: Only support WAV format audio.

- window display scale: Set the video display scale, users can select 16:9, 4:3 and full screen.
- Remember login: user can log in directly next time after select **Auto login.**
- Remember to open preview: Users can get continuous video preview as who turn off the software directly before, and the record video stored also.
- Local record configuration



Select the saved path of local video, set reserve space and whether cycling the video. It will work after modified the param and click the button of modify.

- Auto switch stream     fast mode     save bandwidth mode
- Click auto switch stream

Sub stream for above 4 split screen, main stream for 1/4 split screen.


Fast mode: Opened the main stream and sub stream simultaneously in fact, it only change the display chars at every stream switch

Save switch stream: It have to turn off the current stream then turn to another stream, the speed is a little slow then Fast mode

- Non click auto switch stream: Right click on the preview window to select the stream type
- Color for front-end video record type

Different color means different video record type for front-end device.

- Time automatic correction(All devices): Click devices and open time correction function.
- Software authorize: Get the devices access authorization, input the devices machine code, see the picture below:




Click the corresponding authorization button, after authorize successfully, reset the software.


- software version: The current software version.

### 2.6.3 users manage

Click users manage in configuration module then enter into the users manager page.



Add user: click **Add** to open the add user page:




Define user name and password, user authority can be subdivided to single device channel when checking . To note here is: If device has no preview authority, it will not offer other permissions, if the channel has preview authority, it support video record automatically.

User modify: Modify the name, password, permission of ordinary user, superuser (It is the first client , we call it root) allowed to modify password only.


User delete: cancel the ordinary user but super-user.

#### 2.6.4 alarm linkage

Click **Linkage config** to enter the alarm linkage setting page. As figure below:



This is used to configurate alarm linkage information and manage the configured alarm linkage . Click new alarm linkage ,as figure below :



Rule name: Rule name (user defined)

Type: Alarm input ,motion detection, video cover, video lost

Source: Select any device channel for alarm linkage

Linkage action: Corresponding actions for alarm signal receiving,  
user can select one or more linkage action including :

- sound: Buzzer alarm
- Map: Alarming on the electronic map
- TV wall: Alarming on the TV wall
- Preview: Pop up a preview window
- Record: Alarm triggered video record
- Capture: Alarm triggered capture
- PTZ: Alarm triggered PTZ control

Action param: Display the relevant action information

Remark : Indicate the alarm information(user defined)

## 2.7 All protocol products function parameters

### Preview

	Digital zoom	Capture	PTZ	Audio	Talk-back	Local video recording	Video parameters	image enhance	Group rotation	Front- end video recording status display
I8	Support	Support	Support	Support	Support	Support	Support	Support	Support	Support
ONVIF	Support	Support	Unsupport DC, IRIS	Support	Support	Support	Support	Support	Support	Support
Hiklife	Support	Support	Unsupport DC, cruise	Support	Unsupport	Unsupport	Unsupport	Unsupport	Support	Support
Dahua	Support	Support	Unsupport DC, cruise	Support	Unsupport	Unsupport	Unsupport	Unsupport	Support	Unsupport

## Playback

	Front-end video recording playback	Local video recording playback	video recording playback capture	Download front-end video recording	Download Local video recording	Change the playback speed	Playback audio preview	Frame display
<b>I8</b>	Support	Support	Support	Support	Support	Support	Support	Support
<b>ONVIF</b>	Unsupport	Support	Support	Unsupport	Support	Support	Support	Support
<b>Hiklife</b>	Support	Unsupport	Support	Support	Unsupport	Support	Support	Support
<b>Dahua</b>	Support	Unsupport	Support	Support	Unsupport	Support	Support	Support

## Map and TV wall

	Map preview	Map local video recording playback	Map front-end video recording playback	Pictures pop up on the map as alarm in	Map monitoring point alarm blink	Video display on the TV wall by decoder	Video display on the TV wall	Audio display on the TV wall	Group video rotation
<b>I8</b>	Support	Support	Support	Support	Support	Support	Support	Support	Support
<b>ONVIF</b>	Support	Support	Unsupport	Support	Support	Support	Support	Support	Support
<b>Hiklife</b>	Support	Unsupport	Support	Support	Support	Unsupport	Unsupport	Unsupport	Unsupport
<b>Dahua</b>	Support	Unsupport	Support	Support	Support	Unsupport	Unsupport	Unsupport	Unsupport

## Log and user configuration

	Alarm log	Operation log	Remote log	Remote configuration	User management	Get channel name	Modify IP	Time correction
<b>I8</b>	Support	Support	Support	Support	Support	Support	Support	Support
<b>ONVIF</b>	Support	Support	Only support abnormal log search	Unsupport	Support	Support	Support	Support
<b>Hiklife</b>	Unsupport	Support	Support	Unsupport	Support	Support	Unsupport	Support
<b>Dahua</b>	Unsupport	Support	Unsupport	Unsupport	Support	Support	Unsupport	Support

## Alarm

	Alarm linkage audio	Alarm linkage map	Alarm linkage TV wall display	Alarm linkage picture pop up	Alarm linkage video recording	Alarm linkage screen capture	Alarm linkage PTZ
<b>I8</b>	Support	Support	Support	Support	Support	Support	Support
<b>ONVIF</b>	Support	Support	Support	Support	Support	Support	Support
<b>Hiklife</b>	Support	Support	Unsupport	Support	Unsupport	Support	Support

Dahua	Support	Support	Unsupport	Support	Unsupport	Unsupport	Unsupport
-------	---------	---------	-----------	---------	-----------	-----------	-----------

Client data backup: As users install the client software, it will create a NVMS\_Data file, click to open this file, please notice **videoMonitorDb.s3db** subfile, all parameters configuration saved in this subfile. When users have to recover the data, replace **videoMonitorDb.s3db** to **C:\NVMS\_Data** file is ok.