



















	8900/Apache/AT&T Pure/HD Diamond/P3600 Trinity/P3600i Trinity/P3650Cruise/P3651Touch Cruise/P4350/P4351/P4500 TyTN/P4550 TyTN 3G/T3333 Touch 2/T4242 Touch Cruise09 /T5353Touch Diamond 2/T7377 AT&TTilt 2/T8282 Touch HD /T8285 Touch HD/T8290 Max Touch 4G/Touch/Diamond/Touch Dual/Touch Pro/Touch Pro 2/X7500Advantage/X7510 Advantage/XV6975 Imagio
		Aria/ Desire/Dream/ Droid Eris/ Evo 4G/Hero/Incredible /Legend/ Magic/Tattoo/Wildfire
		CT810 Incite /GM730 Eigen /GM750 /GT810H /GW550 /GW820 eXpo/KS20 /VS750 Fathom
		GT540 Swift / GW620 Eve / KH5200 Andro-1 / LU2300 Optimus Q / VS740 Ally
		DX650 / DX900 / E100 beTouch / E101 beTouch / M900 / neoTouch / X960
		E110 beTouch / E400 beTouch / Liquid
		3250/5230/5233/5235 Comes With Music/5320 XpressMusic /5500 Sport/5530 XpressMusic/5630 Xpress Music/5700 XpressMusic/5730 XpressMusic/5800 XpressMusic/6110 Navigator/6120 classic 6121 classic 6122c/6124 classic/6210 Navigator/6220 Classic 6290/6650 Fold 6720 Classic 6730 classic 6788/6790Mako/ C5/ C6/ E50/ E51/ E52/ E55/ E60/ E61/ E62/ E63/ E65/ E66/ E70/ E71/E72/ E73 Mode/E75/E90/N71 /N73/N75/N76/N77/N78/N79/N80/N81/N82 N85/N86/N91/ N92/ N93/ N95/ N96/ N97/ N97 Mini/ X6
		GT i7110 / GT i8510 Innov8 / GT i8910 Omnia / SGH G810



















 		/ SGH i450 / SGH i550 / SGH i560 / SGH L870
		GT B7300 OmniaLITE/GT B7320 OmniaPRO/GT B7330 OmniaPRO /GT B7610 OmniaPRO/GT B7620 Giorgio Armani/GT C6620/GT C6625 Valencia/GT i8000 Omnia II/SCH i220 Code/SCH i760 /SCH i770 Saga/SCH i910 Omnia/SCH i920 Omnia II/SGH i300 /SGH i600/SGH i607 Blackjack/SGH i617 Blackjack2/SGH i627 Propel Pro/SGH i637, SGH i710/SGH i718/SGH i740/SGH i780 /SGH i900/SGH i908 Omnia/SPH i325 Ace/SPH i350 intrepid/SPH IP830/SPH M7350 OZ Omnia



















 Sony Ericsson		U1 Satio / U5 Vivaz / U8 Kanna
		M1 Aspen / X1 Xperia / X2 Xperia



		DX650 / DX900 / E100 beTouch / E101 beTouch / M900 / neoTouch, X960
		E110 beTouch /E400 beTouch / Liquid

 MOTOROLA		A3000 / A3100 / Q / Q9
		A555 Devour/A955 Droid II/Droid/Droid X/i1/ MB200 Cliq/ MB300/ MB501 Cliq XT/ MB511 Flipout/ Moto XT800/ MT710 ZHILING/ Quench XT3/ XT701 XT720 Motoroi

		E850 / N810
---	---	-------------

		M10 Nuvifone/ M20 Nuvifone/ P320/ P505/ P525/ P526/ P527/ P550/ P552/ P750/ P835
		SMT 5600
		E72 / P51
		Axim X50
		Mini 3iX / Streak / Thunder
		310/535/565/566/577W/585/586w/595/818 Pro/828/838 /838Pro/900/C720/C750/C800/D810/M700/P800/S1/ S600/S900/T2222 Touch Viva/U1000
		g-Smart i120
		GSmart G1305 Boston
		iPAQ 510 Mobile Messenger / iPAQ HW6500 / iPAQ K3 Glisten
		i9502 Ultimate / i-mate Jamin / i-mate JAQ / i-mate JAQ3/ i-mate JASJAM / i-mate JASJAR / i-mate K-JAM

	 E-4000 Solo
	 M6000 Zio
	 ET980 / i921
	 Xda Argon/Xda Atmos/Xda Atom/Xda Atom Exec/Xda Atom Life/XDA Diamond Pro/Xda Graphite/XDA Ignito/Xda Nova /Xda Orbit/Xda Orbit II/XDA Serra/XDA Star/XDA Stealth/DA Stellar/XDA Trion/Xda Zinc
	 SPV C100 / SPV C600 / SPV M2000 / SPV M3000 / SPV M3100 / SPV M5000/ SPV M600 / SPV M700
	 Treo 700 / Treo 750 / Treo 800 / Treo 850 Pro
	 C810 Duo / C820 Matrix Pro
	 IMA600S Sirius
	 IS01
	 Dash/ Dash 3G/ MDA AMEO/ MDA Basic Opal/ MDA Compact IV/ MDA Touch/ MDA Touch Plus/ MDA Vario III/ Shadow/ Shadow 2009/ Wing

		G2 Touch/ MyTouch 3G/ myTouch 3g Slide/ Pulse
		G710 / G900 / TG01
		1231 / VPA Compact IV / VPA III
		E811
		X850 Racer
		Blaze / X5E
		Garminfone
		Nexus One
		U8110 / U8230
		General Mobile DSTL1



BlackBerry 8900/ BlackBerry 9000 Bold/ BlackBerry 9100 Pearl (9105 Pearl) /BlackBerry 9630 Tour /BlackBerry 9650 Tour2 /BlackBerry 9700 Onyx (Bold, 9020)



Apple iPhone 3G/3GS (OS 3.0 or later)
Apple iPhone 4 / iPod touch, iPad



D-1100 / D-1111 / S-1000



SX66



QTEK 8010 /QTEK 8020 / QTEK 9000 / QTEK 9090 / QTEK 9100 /Qtek 9600 / 8500



MY S-7