

Code: RUD-6-LKY

HARDWARE KEY **RUD-6-LKY** ROGER

The hardware key RUD-6-LKY is required when using the licensed versions of the VISO EX and RCP Master3 / RCP Master4 programs. The device should be connected to the USB port of the computer on which the license server is installed and separately purchased the appropriate software license.

ATTENTION! Regardless of the number of workstations with the VISO EX and/or RCPM3 software, the license server is installed on one computer in the LAN and one key RUD-6-LKY is connected to it.

Attention! It is not possible to buy the RUD-6-LKY key alone. It is sold only with RCP / Viso licenses.



Power supply:	5 V DC - from USB port
Operation temp:	5 ... 45 °C
Weight:	0.02 kg
Dimensions:	88 x 30.5 x 14.5 mm
Manufacturer / Brand:	ROGER
Guarantee:	3 years

