

Code: TT-12E

THERMOSTAT **TT-12E**

Using the heaters with thermostat inside the outdoor housing enables stable and safe camera and lens working conditions, and eliminates the undesirable phenomena such as: sweating, rapid freezing and condensation of water on the glass of the housing at low temperatures. The device turns the heaters on when the temperature inside the housing is below the specified value.

After open the camera housing, you need mount the thermostat on the end of housing's mounting panel and switch the power on DC +12V to the red wire and GND to the black one. The device is extra protected against reverse polarity connection of the power voltage. After mounting it is necessary to test the correct camera work. Please close the jumper on the thermostat board (by a screw driver for example). The heaters will turn on. Then check the correct camera work.



| | |
|--------------------------------------|---------------------------------|
| Thermostat switching on temperature: | 3 °C |
| Housing type: | TP-601, TP-606, TP-607, TH-200 |
| Camera power supply adapter: | — |
| Power supply: | 12 V DC |
| Power / current consumption: | max. 5.5 W / 460 mA |
| Dimensions: | 57 x 32 x 15 mm (heaters board) |
| Manufacturer / Brand: | DELTA |
| Guarantee: | 3 years |