

Warning!

Please read the user manual included in this work as it contains important information related with safety of installation and use of the device.

Only persons who read the user manual may use the device.

The user manual must be kept because it may be required in the future. The device is to be used exclusively for purposes specified in this user manual.

The device must be unpacked prior to starting-up. After removing the packaging make sure the device is in working order.

If the product has defects, it should not be used until it is repaired.

The product is intended for use at home and commercial use and may not be used for other than intended use.

The manufacturer is not liable for damages resulting from not adhering to the rules contained in the user manual, therefore, we recommend to follow the aforementioned safety rules for operation and maintenance of the device. In this way you will ensure yourself safety and avoid causing damage to the device.

The manufacturer and the supplier are not liable for losses or damages arising out of the product, including financial or intangible losses, loss of profits, income, data, pleasure from use of the product or other products related with it - indirect, incidental or consequential loss or damage. The above provisions apply whether the loss or damage concerns:

1. Deterioration of quality or the lack of operation of the products or products related with it due to damage as well as the lack of access to the product when it is undergoing repair, which results in stoppage the loss of user's time or a break in business activity;
2. Improper results of operation of the product or products related with it;
3. It applies to losses and damages according to any legal category, including negligence and other losses, termination of a contract, expressed or implied guarantee and strict liability (even if the manufacturer or the supplier was notified about the possibility of occurrence of such damages).

Safety measures:

Particular attention at designing was directed to quality standards of the device where ensuring safety of operation is the most important factor.

The device must be secured against contact with caustic, staining and viscous fluids.

More and more home devices to LAN, RTV, CCTV installations are made with a view to the RACK system, so that their installation is aesthetically pleasing, and that devices are protected against accidental mechanical damages.

The EPRADO-R19-42U/800X800 cabinet is suitable for mounting all sorts of devices in standard 19" rack housings. Ideal solution for installing DVRs, power units, splitters, headends, network devices, etc. Inside the cabinet can be also place the devices that are not in standard RACK-19" housings, for example DVRs, multiswitches, RTV-SAT amplifiers, modulators. For this purpose the user should mount additional shelf/shelves available for RACK cabinet.

The RACK cabinet has many openings ensuring adequate air circulation. Additionally, it is possible to install fans to increase the ventilation.

Non-rack devices can be mounted on the four-point mounted shelves, with a depth of max. 660 mm.

The EPRADO-R19-42U/800X800 cabinet is intended for self-assembly.





User Manual

Code: EPRADO-R19-42U/800X800
STANDING RACK CABINET **EPRADO-R19-42U/800X800**

Internal width:	19 "
Internal height:	42 U
Internal depth:	660 mm
External width:	800 mm
External height:	2072 mm
External depth:	800 mm
Holes for fan coolers:	105 x 105 mm (4 places) 335 x 260 mm (total size of the hole)
Bearing capacity:	800 kg
Color:	Black RAL9004
Door:	• Front: glass • Side: metal, snap-in • Rear: metal, hinges
Main features:	• Cable entries are placed from the top and bottom • Cable entry in the base with dimensions of 380 x 280 mm • Removable side panels • Possibility to mount the door as left or right • 4 keys included • Four rack rails for mounting devices (2x front, 2x rear) • The cabinet moves on the lockable castors, stabilizing by twisting 4 leveler legs
Weight:	112 kg
Guarantee:	3 years

Front view:



Rear view:





The correct order of assembly:
Assemble two frames of the sides:



Whole frame connect to the base and cabinet cover:



Next add the inner support elements:






Side view (no mounted sides and back cover):



Front view:



Rear view:



The cabinet has 2 opened cable trays which can be mounted to both the back and front:



Cable entry in the base with dimensions of 380 x 280 mm:



Holes for fan coolers:



Grounding:



In the kit:





User Manual

Code: EPRADO-R19-42U/800X800
STANDING RACK CABINET **EPRADO-R19-42U/800X800**

PACKAGE

Dimensions (L x W x H): 0x0x0 mm	Gross Weight: 0 kg
----------------------------------	--------------------