

Warning!

Please read the user manual included in this work as it contains important information related with safety of installation and use of the device.

Only persons who read the user manual may use the device.

The user manual must be kept because it may be required in the future. The device is to be used exclusively for purposes specified in this user manual.

The device must be unpacked prior to starting-up. After removing the packaging make sure the device is in working order. If the product has defects, it should not be used until it is repaired.

The product is intended for use at home and commercial use and may not be used for other than intended use.

The manufacturer is not liable for damages resulting from not adhering to the rules contained in the user manual, therefore, we recommend to follow the aforementioned safety rules for operation and maintenance of the device. In this way you will ensure yourself safety and avoid causing damage to the device.

The manufacturer and the supplier are not liable for losses or damages arising out of the product, including financial or intangible losses, loss of profits, income, data, pleasure from use of the product or other products related with it - indirect, incidental or consequential loss or damage. The above provisions apply whether the loss or damage concerns:

1. Deterioration of quality or the lack of operation of the products or products related with it due to damage as well as the lack of access to the product when it is undergoing repair, which results in stoppage the loss of user's time or a break in business activity; 2. Improper results of operation of the product or products related with it;

3. It applies to losses and damages according to any legal category, including negligence and other losses, termination of a contract, expressed or implied guarantee and strict liability (even if the manufacturer or the supplier was notified about the possibility of occurrence of such damages).

Safety measures:

Particular attention at designing was directed to quality standards of the device where ensuring safety of operation is the most important factor.

The device must be secured against contact with caustic, staining and viscous fluids.





DELTA-OPTI Monika Matysiak; https://www.delta.poznan.pl POL; 60-713 Poznań; Graniczna 10 e-mail: delta-opti@delta.poznan.pl; tel: +(48) 61 864 69 60

2024-05-23

cabinet.

LE-601946



User Manual Code: LE-601946 surface-mounting hermetic distribution cabinet 36-modular **LE-601946** RN65 LEGRAND

| Method of mounting: | Surface-mounted |
|------------------------------|---|
| Number of mounted modules: | 18 x 2 rows |
| Spacing between TH 35 rails: | 150 mm |
| Transparent door: | ¥ |
| Main features: | Weatherproof cabinet Fully reversible door and cabinet Removable chassis and faceplates The TH 35 rail with 2-position mounting for modular products Can be fitted with perforated plates and solid faceplates for mounting non-modular products Lockable door handle, sealable cover and faceplate Rated voltage : 400 V AC, 50 / 60 Hz Max. current : 90 A Short-circuit current : 10 kA Equipped with terminal blocks and modules blanking plates |
| Equipment: | • Terminal blocks 1 x (21 x 1.5 16 mm ² + 1 x 6 25 mm ²) 3 x (8 x 1.5 16 mm ²) • Module blanking plates : 2 x 5 pcs |
| Material: | Self-extinguishing |
| Color: | Light gray |
| "Index of Protection": | IP65 |
| IK rating: | IK09 |
| Compliance with standards: | PN-EN 60439-3, IEC 60695-2-11, IEC 62262 |
| Operation temp: | -25 °C 40 °C |
| Weight: | 4 kg |
| Dimensions: | 448 x 432 x 161 mm |
| Manufacturer / Brand: | LEGRAND |
| Guarantee: | 2 years |

Front view:





User Manual Code: LE-601946 SURFACE-MOUNTING HERMETIC DISTRIBUTION CABINET 36-MODULAR LE-601946 RN65 LEGRAND



Bottom view:



Internal view of the housing:









Mounting side view:





User Manual Code: LE-601946 surface-mounting hermetic distribution cabinet 36-modular **LE-601946** RN65 LEGRAND



PACKAGE

Dimensions (L x W x H): 0x0x0 mm Gross Weight: 0 kg



DELTA-OPTI Monika Matysiak; https://www.delta.poznan.pl POL; 60-713 Poznań; Graniczna 10 e-mail: delta-opti@delta.poznan.pl; tel: +(48) 61 864 69 60

LE-601946